

The purpose of this manual is to provide simple indications to report to the person in charge of the maintenance or assistance of the device for the diagnosis of any malfunctions.

The unit should not be opened (not even for the replacement of liquid bags) by unqualified personnel.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. If there are any issues or problems with the fog machine please call your service provider



MODULAR 200
MODULAR 300
MODULAR 400
MODULAR 500
MODULAR 800

 **EMPTY
RESERVE**

RED LED (right)

ON: Error (Empty bag or low fluid, Mains power off/Battery low) or Fault
OFF: No error condition.

 **ARM
FAULT**

BLU LED (center)

ON: Unit is armed and ready to shoot (with green led ON).
OFF: Unit is disarmed, shot not possible.

 **HEATING**

GREEN LED (left)

ON: Unit has reached the correct temperature.
OFF: Unit is warming, no shot possible.



The EMPTY signal also means that fluid is going LOW.
It means that the unit has shot at least 100 seconds since last reset (Modular 200).



The central RED low power light means unit is powered on.
The RED FAULT led is on the top of the board.



USER MANUAL



MODULAR

200

300

400

500

800

ENGLISH MANUAL